



SS-FD23-02 Start/Stop Wiring Installation (Ignition Switch)

Start/Run Wire = Cut Wire (CDC34 WH-OG)

Splice Yellow Wire from SS-FD23-02 to wire running to **Ignition Switch**

Splice White Wire from SS-FD23-02 to wire running to **Body Control Module**

Start Wire = Splice Violet/Orange wire from SS-FD23-02 to CDC35 BU-WH (**START** Pin 1 **Ignition Switch** and **START** Pin 4 **Body Control Module**)

