

SS-FD23-03 Ignition Wiring Diagram

SS-FD23-03 Start/Stop Wiring Installation (Ignition Switch)

Start/Run Wire = Cut Wire (CDC34 WH-OG) START/RUN

Splice Yellow Wire from SS-FD23-02 to wire running to Ignition Switch (Pin 2)

Splice White Wire from SS-FD23-02 to wire running to Body Control Module (Pin 3)

Start Wire = Splice Violet/Orange wire from SS-FD23-02 to CDC35 BU-WH (START Pin 1 Ignition Switch and START Pin 4 Body Control Module)

